

OpenUV380 Instructions by Ian Spencer DJ0HF v1.0A 27.8.2022

Keypad layout

The keypad of the UV380/RT3S is directly below the display so in the lower third of the front panel.

It has 4 rows of buttons vertically. Starting on the top row at the left the first button is the green OK or Menu button, to the right of that is the UP arrow key, and then the DOWN arrow key and to the right the red Cancel button.

The next 3 rows are the alpha numeric keypad and other characters, though we are only interest in using the numbers and special keys here to enter things like talk-groups etc. so the 2nd row from the left is 1 then 2 then 3 then star or asterisk. The row below that is 4 then 5 then 6 and 0 and the final row at the bottom is 7 then 8 then 9 and then the hash or pound key.

On the left hand side of the radio are 3 push buttons the top button is the button SK1 and below that is the long PTT button and below that the SK2 button. On the top of the radio is the channel change rotary knob and to the right of that the volume control with on/off switch.